



Samsung Galaxy Note SD Card Replacement

This guide shows you how to replace your phone's SD card.

Written By: David Ritter



INTRODUCTION

The SD card holds your phone's external memory. Replace or remove the SD card if you want to change how your phone deals with memory storage. Check the device's [troubleshooting page](#) if you think your SD card is malfunctioning.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Battery



- Make sure the screen is face-down and the camera is opposite you.
- Insert the flat end of a spudger into the phone's top right rectangular slot.
- Use the spudger as a lever to pry open the back of the phone.

Step 2




- With the spudger still inserted, carefully slide the spudger down the side of the phone.
- Gently peel off the back cover with your hand.

Step 3



- Place the spudger in the battery's bottom right slot.
- Gently pry to remove the battery.

Step 4 — SD Card



- Pull out the micro SD card located in the upper right slot (above the battery).

To reassemble your device, follow these instructions in reverse order.